

# THREE MOVEMENT TIME LOCK MOUNTING PATTERN

## TMI, S&G, STB, LEFEBURE, LAGARD, & RELHOR

### Installation Notes

1. Install all four (4) shock washers. The washers are made from neoprene and designed to absorb transitional shock, preventing damage to the movements.
2. A gap of 0.03125 must exist between the snubber and snubber bar in the fully locked condition. With the door open, extend and lock the bolt work, followed by raising the snubber slide to the fully locked position.
3. 3/8" X 16 X 3/4" Button Head Bolts are supplied for installing the base plate. Minor alignment abnormalities between the snubber bar and base plate are corrected by loosening these bolts and manipulating the base plate in the desired direction.
4. Final calibration for "0" hour opening was done at the factory. The installer is responsible to verify that the time lock will open at "0" hour and that all components function smoothly. **CHECK FUNCTIONALITY WITH THE DOOR OPEN.**

